

You will need:

Defender Base Channel

Defender Top Trim – floor or fascia connect

1. Install the channel and fix down as per the stated instructions. If using floor connect top trim, make allowance for how this will fit before installing the channel.
2. Now install the glass according to relevant instructions.
3. Pre-install the balloon gasket into the top trim, rather than the finish profile that comes with the channel.
4. Complete the process by pressing the top trim onto the top of the channel. Depending on the top trim(s) used, one of the standard snap-on finishing profiles supplied with the channel will need to be used as well.

Note:

Technical information, dimensions and illustrations in this guide are for guidance purposes only. We reserve the right to change product sizes and details without prior notice. We always recommend that the purchaser checks the sizes of the actual batch purchased prior to drilling other materials.

All advice or assistance relating to our products is given in good faith but without obligation and subject specifically to the exclusion of any liability whatever on our part or on the part of our staff for damages whether direct or consequential. It is the buyer's responsibility to establish the suitability of the product and materials for the purpose for which they are purchased.