

Tools needed:

Component Adhesive – Quickcode 112
Adhesive Activator – Quickcode 113
Soft cloth and cleaning product

Instructions:

1. Make sure the parts that are to be glued are to hand, and you know exactly where each part goes. We suggest you do a dry run first to ensure you have everything you need; when installing a balustrade this will prevent expensive mistakes.
2. Clean both parts thoroughly. Make sure the surfaces to be glued are clean, dry and grease free.
3. Spray the activator onto the spigot portion of the component.
4. Once the activator has evaporated, apply adhesive to inside of tube only and assemble immediately, moving the parts slightly to ensure mixing of the adhesive with the activated surface(s).
5. **Please note:** it is important to only put glue on the inside of the tube, so there is no visible glue on the outside of the tube for a professional finish.
6. Ensure that the components are assembled how you want them. There is a small amount of movement possible before the glue goes off.
7. Adhesive cure times is dependant on factors such as ambient temperature.

Note:
Technical information, dimensions and illustrations in this guide are for guidance purposes only. We reserve the right to change product sizes and details without prior notice. We always recommend that the purchaser checks the sizes of the actual batch purchased prior to drilling other materials.

All advice or assistance relating to our products is given in good faith but without obligation and subject specifically to the exclusion of any liability whatever on our part or on the part of our staff for damages whether direct or consequential. It is the buyer's responsibility to establish the suitability of the product and materials for the purpose for which they are purchased.